

THURSTON BUILDING SYSTEMS

Surefire User Manual

Specification

GENERAL DESCRIPTION

Surefire anti-vandal low maintenance security buildings are designed, manufactured and independently tested to meet clause 12.4 of the Joint Code of Practice on the Protection from Fire of Construction Sites and Buildings Undergoing Renovation, and therefore offering the best of protection in the event of fire.

FLOOR

Agreement certified moisture resistant heavy duty tongued and grooved flooring grade strand board fixed to joists. Galvanised steel joists at 300mm centres supported on welded steel angle perimeter base frame which is in turn supported on rolled steel channel skids extending the full length of the building. The whole floor is underdrawn with arson resistant galvanised sheet steel. The floor covering is a heavy-duty flexible sheet vinyl, with continuously welded joints, and is bonded to floorboards. Floors are designed to provide for a uniform floor loading of 2.5kn/m². The floor can be insulated as an optional extra.



EXTERNAL WALLS

The external walls are fully galvanised structural steel panels 305mm wide with integral supports. The wall sections are welded to the perimeter of both base frame and roof perimeter gutter. Internal finish is vinyl wall covering laminated to 12.5mm plasterboard lining, providing a class 'O' surface spread of flame, with extruded plastic joint strips and a 12.5mm paper faced plasterboard backing board. Alternative finishes are available on request. Wall cavities are insulated with 80mm non combustible fibrous insulation which provides a 'U' value of 0.44w/m²c. External finishes are spray applied compliant paint to B.S. 4800. Zinc rich galvanic primer is applied to all external mild steel surfaces and weld areas. All panel joints are polyurethane sealant sealed. Natural trickle ventilation is achieved by the incorporation of high and low level permavents which incorporate flame arrestor gauze.

ROOF

Heavy duty fully galvanised, mechanically interlocking structural steel panels are riveted, bonded and sealed with polyurethane adhesive. Rainwater is discharged at each corner via a perimeter galvanised steel guttering system to which optional extra rainwater pipes can be included if required. The internal ceiling finish is steel lined with a paint finish. The roof also incorporates fibrous insulation providing a 'U' value of 0.44w/m²c.

WINDOWS

Maintenance free aluminium framed polyester powder coated windows with side sliding casements and satin anodised aluminium casement stays glazed in 4mm toughened glass. Heavy-duty horizontal self closing sliding galvanised steel window shutters for internal single person operation are fitted as standard including locking bolts and other anti-jemmy features.

EXTERNAL DOORS

External doors are constructed from galvanised steel, fully insulated. With a clear opening of 840x1940mm the single outward opening door is hung on a zinc plated full height 'piano' hinge welded to both door and steel frame and is fitted with two five lever mortice deadlocks, a mortice latch, SAA lever furniture, and anti-jemmy security features. The door also incorporates fibrous insulation providing a 'U' value of 0.697w/m²c.

INTERNAL DOORS

When fitted the factory pre-assembled, 726mm wide doors are fitted with chrome furniture and either a latch handle; optional mortice lock or bathroom furniture.

INTERNAL PARTITIONS

- Standard:-

Class 'O' vinyl faced 12.5mm plasterboard partition with extruded plastic joint strips and 1.25mm galvanised steel channel studding.

- Removable:-

A durable class 'O' vinyl faced 9mm plywood partition with extruded plastic joint strips and 1.25mm galvanised steel channel studding. Partitions fitted over floor coverings for ease of relocation.

- Demountable:-

Class 'O' vinyl faced 12.5mm plasterboard partition with extruded plastic joint strips and 1.25mm galvanised steel channel studding. Partitions fitted over floor coverings for ease of transfer.

JACKLEGS

Manufactured from rectangular hollow-section steel with welded base and head plates telescopic legs and unique double pin dowel adjustable at 100mm centres that enable triple stacking of units.

Surefire Dimensions




Table 1 Surefire dimensions in metres

Surefire Model	Overall External			Foundation Centre		Intermediate Exterior			Internal		
	A	B	C	D	E	F	G	H	Length	Width	Height
SFO1208	3.81	2.79	2.40	2.69	3.05	0.305	2.55	2.70	3.48	2.23	2.42
SFO1608	5.03	2.79	2.40	2.69	4.27	0.305	2.55	2.70	4.70	2.23	2.42
SFO2008	6.25	2.79	2.40	2.69	4.27	0.915	2.55	2.70	5.92	2.23	2.42
SFO2408	7.47	2.79	2.40	2.69	4.27	1.524	2.55	2.70	7.14	2.23	2.42
SFO2010	6.25	3.41	3.01	3.31	4.27	0.915	3.16	2.70	5.92	2.84	2.42
SFO2410	7.47	3.41	3.01	3.31	4.27	1.524	3.16	2.70	7.14	2.84	2.42
SFO3210	9.9	3.41	3.01	3.31	5.49	2.134	3.16	2.70	9.58	2.84	2.42

A Overall length including gutters
B Overall width including legs
C Width of unit
D Between leg centres on width

E Between leg centres on length
F Centre of leg to end of unit
G Width of roof including gutters
H Height bottom of skid to top of roof

Transport and Handling

Thurston Building systems can deliver your preferred *Surefire* unit directly to your factory, site or point of use. If you wish to relocate your building Thurston Building systems can provide this service for you. However, *Surefire* buildings have been designed to make relocation and transportation as simple as possible and any reputable haulage contractor can readily undertake the process.

JACKLEG OPERATION

The jackleg raising and lowering sequence should not be undertaken in high winds, and should ideally be carried out on firm level ground. Prior to jacking the unit, checks should be made to ensure that the legs are fully secure and that the jacklegs and pin mechanisms are in sound condition. During transit the inner jacklegs should be fully retracted and retained using the jackleg pins provided, which must pass through the matching holes in both inner and outer legs. The pins should be secured in position with the clips provided as illustrated to prevent any movement due to vibration.



To raise a unit

Remove clips and pins and drop all inner legs to the ground. Fully lower the bottle jack and tighten jack valve and operate jack to expose higher hole. Insert pin and replace clip. Release jack pressure, position jack to the remaining leg on the same elevation and repeat the operation as described earlier. Repeat the same operations on the opposite side of the unit.

To lower a unit

Fit bottle jack to leg tighten jack valve, operate jack to relieve the pin of pressure. Release the pin and retract the telescopic inner leg to the desired height whilst ensuring that excessive reductions do not cause unit instability on uneven ground. Release jack pressure, position jack to the remaining leg on the same elevation and repeat the operation as described earlier. Repeat the same operations on the opposite side of the unit.

CRANE HANDLING

Depending on site access or location it may be necessary to position the unit using a mobile crane. Each unit has secure craning points; crane shackles/hooks must be of the correct rating. All craning points must be used to lift the unit, with equal chain lengths to ensure an even distribution of load. The minimum chain lengths specified in table 2 below must be used. The maximum weight of the unit must **not** exceed the maximum lifting weight indicated on the specification plate which can be found on the bottom skirt of the building. The minimum crane capacity will depend on the maximum weight of the unit to be lifted and the overall reach necessary to position the unit. Your local craneage contractor should be consulted and will advise on suitable lifting plant and route planning to ensure low bridges and obstructions are avoided.

TABLE 2

Surefire Model	Minimum Sling Length (Meters)	Maximum Weight (Kg)
SFO1208	4.06	2770
SFO1608	5.04	2770
SFO2008	5.04	2770
SFO2408	5.04	6000
SFO2010	5.04	2770
SFO2410	5.04	6000
SFO3210	6.41	6000

TRANSIT

Transit by platform lorry or trailer on public roads must comply with statutory legislation including Road Traffic Act, Construction and Use Regulations as well as any Local Authority regulations that may apply.

The most important aspects to consider is the length and width of the building to be transported, and when the building skids are positioned on the lorry bed, the overall height, and if applicable, the overhang of the *Surefire* unit.

Lashing locations are provided to each unit at jackleg positions to enable secure lashing using chains. Ensure that there are no loose laid items within the unit and that external doors and shutters fastened, and locked, prior to departure.

It is also essential that prior to transportation that all windows, shutters and doors are locked and bolted into the closed position, and that all fixtures and fittings within the unit are securely fixed in place.

ACCESS TO SITE

The following aspects will need to be taken into account to ensure that any problems on site are minimised and an appropriate standard of health and safety is maintained.

- Route and access to site – if in doubt arrange for a local haulier to survey route and access prior to delivery.
- Space on site for manoeuvring lorry, and crane if one is to be used.
- Potential hazards in relation to extended crane jib, e.g. overhead power cables.
- Combined mass of load and vehicle must be considered relative to ground conditions – temporary tracking may be required.

Siting and Foundations

The Surefire range of buildings has been designed to withstand the extremes of the U.K. climate, and the strength and durability of our units has been proven by many years of experience in extreme environments. However, consideration of site conditions is necessary where locally the building may be subject to chemical or exposed coastal sites. In such circumstances additional measures may be necessary and Thurston Building Systems will be pleased to advise.

FOUNDATION DETAILS

The standard range of Surefire buildings can be sited using the jacklegs on any reasonable level site. Thurston Building Systems would be pleased to provide foundation loading recommendations upon request.

The building must be positioned so that all four legs carry the weight of the building. The building should be lowered as close to ground as possible, particularly on exposed sites, and the pins securely located in each leg, plus safety clips.

On sloping sites it is quite satisfactory for one end or one side of the unit to be supported by extending the inner leg. In such circumstances it is important that all pins are securely located and that the maximum leg extension does not in any event exceed 750mm. N.B.: If the building is on an exposed or sloping site, bolting down of the unit is advisable.

Metal shims may be required to ensure the unit is level and adequately supported. Buildings may be supported directly onto the steel base frame when jacklegs are not required.

STACKING

When stacking Surefire buildings it is important that the building foundations are capable of withstanding the full loads of all buildings, including all imposed snow loading and wind loads. This will generally involve the placement of concrete foundations, and competent professional advice should be sought to ensure that adequate provisions are made.

The maximum foundation loads for single and two storey Surefire buildings are given in Table 3. The loads are based on uniformly imposed floor loads not exceeding 2.5KN/m², and a basic wind speed of 50m/s (single and two storey only, three storey is subject to an engineer's recommendation).




FIG. 1




FIG. 2 (illustrates triple stacked foundations)

FOUNDATION LOADS

Foundation loads for Surefire buildings loads are given for single and two storey buildings in Table 3 below. Loads are given for each leg and based on a floor loading of 2.5KN/m². Please request specific advice for three storey buildings from Thurston Building Systems, Fig. 2 above illustrates a typical 3-storey foundation arrangement.

TABLE 3

Surefire Model	Single Storey (KN)	Two Storey (KN)
SFO1208	17.56	32.49
SFO1608	23.41	43.31
SFO2008	29.26	54.12
SFO2408	35.11	64.96
SFO2010	36.70	67.89
SFO2410	44.04	81.47
SFO3210	58.72	108.63

The lower building must be adequately anchored to the foundations to prevent overturning and instability in high winds. Expansion bolts should be used to secure the leg base plate to the foundations. The inner legs must be retracted and the pin secured through the outer leg. Under no circumstances should the legs be extended when multi stacking Surefire units. The jacklegs on the upper buildings must be retracted with pins passing through the third hole of the inner leg and the holes in the outer leg. Use only the pins and bolts provided to bolt upper building to lower building via the leg base plate and top plates, with two bolts to each leg position.

Optional Surefire Variations

Surefire buildings can be linked together on site to form various configurations or layouts to suit your particular needs. Linking of Surefire buildings is accomplished using a purpose made linkway. This provides an effective and reliable method of linking buildings together. installation by Thurston Building Systems where fire certification is required.

The following linking arrangements can be achieved with the standard Surefire building: -


- Side to Side.
- End to End.
- Vertically (up to three storeys).
- Combinations of the above.

Interlinking is also possible with different sized units throughout the range.

OPTIONAL EXTRAS

An extensive range of options is available to further enhance the tough and already well equipped Surefire range, some of which are listed below: -

- Anti-vandal steel or black plastic rainwater pipes.
- Insulated floors.
- Internal partitions and doors.
- Electric heating.
- Kitchen/Canteen and Changing room furniture and fittings.
- Additional Electrical and I.T. Fittings.
- External staircase and landings.
- External corporate colour schemes.
- A comprehensive range of plumbing fittings.
- Removable external door and frame.



REGULATIONS AND STATUTORY LEGISLATION

When moving, linking or stacking units care should be taken that the layout formed by the linked buildings complies with relevant legislation – this will in general be the Building Regulations and the Fire Precautions Act. It should also be noted that any local health and safety arrangements including permit to work, induction procedures etc. should be taken into account.

CONNECTION OF SERVICES

- Electrical Installation

The electrical installation is designed and installed in accordance with the requirements of the IEE Regulations 17 th Edition 2008. Wiring is by twin and earth PVC insulated cables enclose in surface mounted PVC TRUNKING. The electrical trunking system are positioned at ceiling level around the internal perimeter of the building, and incorporate a detachable PVC capping piece to provide full access to wiring

All circuits are wired to a multi-way consumer units positioned at high level, with terminals for direct connection to the site electrical supply. All circuits are provided with overload protection utilising miniature circuit breakers and RCD. The type of supply which may be either single or three phase depending on load requirements, and assessed maximum demand, are indicated on the certificate.

The electrical installation is inspected and tested in accordance with IEE Regulations, and relevant certificate "Transportable Building Electrical Installation certificates" is supplied with the building, please ensure that the certificate is the correct one and is kept safely. On installation, any live testing should be carried out by an N.I.C.E.I.C contractor and all tests inserted on to electrical completion certificate once the building is live. This is recommended for every building relocation and re-connection.

On Installation or relocation

Item	Details	Maximum Frequency
RCD (Main Switch)	Check the incoming R.C.D (MAIN SWICH) is working correctly and that it is checked regularly.	At each relocation
Water Heaters	Check that all water heaters have the water turned on before switching on the isolators.	At each relocation
Lighting	Carry out functional checks on all lights, and ensure all lamps are in the correct position	At each relocation
Room Heaters	Check all room heaters have all the packaging removed .	At each relocation
Sockets	Check all sockets are working correctly	At each relocation
Thermostats	Check all thermostats that control heaters are working correctly	At each

		relocation
PIR's & control features	Check operation of PIR's	At each relocation

- Natural Gas and LPG Installations

Natural Gas installations, where installed, are carried out in accordance with the GAS SAFETY (Installation and Use) REGULATIONS 1984 and recommendations DM2 Code of Practice for Gas Installations. Completed installations are tested in accordance with all relevant recommendations, and a gas soundness test certificate is supplied with the building. LPG installations are designed, installed and tested in accordance with BS 5482 Pt 2 1988, and a relevant gas soundness test certificate is supplied with the building. Ventilation air for combustion is provided by fixed wall ventilators positioned at high and low level in accordance with BS 5482 Pt 1. At no time should any of the ventilators be covered or obscured. Health and Safety information for the use of LPG Installations is supplied with the building. When the building is in use, this information should be prominently displayed to users and occupants alike. No additional gas fittings should be incorporated without first checking that adequate ventilation is available.

- Water

Hot and cold water distribution, when installed, is in accordance with the recommendations of BS 6700: 1987. Completed installations are pressure tested prior to despatch. Details of the test are supplied with each building.

- Drainage

Soil and waste systems are installed in push fit polypropylene and PVCu pipework, in accordance with BS 5572.

- Telephones

Attention is drawn to the Telecommunications Act 1984 which requires apparatus to be approved before it can be connected to networks run by British Telecom.

- Any alteration to, or servicing of, the units must be carried out by a suitably qualified operative.

Inspection and Maintenance

Surefire buildings have been developed over many years to provide tough and durable accommodation for a great variety of uses, requiring little maintenance throughout their useful life. However, where a high level of aesthetic appearance is paramount or where in use conditions are particularly severe, positive action can be taken in the form of regular maintenance and inspection as listed, to retain the Surefire building in prime condition.

INSTALLATION CERTIFICATES

All installation certificates and instructions for equipment fitted to the services will be itemised on a Warranty Notice – checklist, delivered with the unit.

To ensure that the terms of the Warranty are effective, the notice should be returned once all the documents have been received.

FIXINGS TO WALLS AND INTERNAL PARTITIONS

- Lightweight Items

Lightweight items such as notice boards, etc. can be fastened directly to internal walls and partitions using proprietary gypsum board fixings with self-drilling action.

- Heavyweight Items

Heavyweight items such as shelving, wall-mounted cupboards, etc., should be fixed to walls and partitions with expanding steel cavity fasteners and where possible into steel uprights. Care should be taken to follow the manufacturers instructions, particularly with respect to pilot hole size and resist over-tightening the fixing screws.

Exceptionally heavy items such as storage water heaters, etc., should ideally be positioned so that the weight is transferred directly to the floor. This can be achieved by first fixing a full height plywood or similar backboard to the wall, with the base of the board supported by the floor.

INSPECTION AND MAINTENANCE SCHEDULE

Item	Details	Maximum Frequency
Welds	Check welds, where appropriate, in the following locations for corrosion. If required clean and prepare the affected area, apply a painted galvanising primary coat and finishing coats as paint manufacturers instructions: <ol style="list-style-type: none"> 1 Light duty lifting eye jackleg brackets 2 Roof steelwork for lifting eyes. 3 Base lifting brackets. 4 Wall panel/roof connections. 5 Wall panel/base connections. 6 All base frame welded joints. 7 Roping down brackets. 8 Base mounted lifting brackets. 9 Roof anchors 10 Low level jackleg mounted lifting bracket 	Annually
Roofs	Inspect for evidence of deterioration of: <ol style="list-style-type: none"> 1. roof panel to panel seals, 2. security and condition of adhesive gaskets at the ends of each roof panel seal 3. Particularly in exposed or coastal/ industrial environments, but generally anyway assess galvanising of roof panels for breakdown, maintain or paint as appropriate 	Annually
Gutters	Check for debris and leaves or damage to gutter, which may cause gutters to overflow and cause pattern staining to external walls.	Annually
Frost protection	Ensure that insulation is in place and that it is not waterlogged. Check that any electrical heating installed for frost protection is in working order.	Annually & As IEE requirements
Overflows	Check that overflows are not blocked and that any discharge can be readily observed.	Six months
Window seals	Ensure that the rubberised window seal have not become dislodged or damaged, replace if necessary. Any surface damage to the powder coating of the window frame to be cleaned and apply touch-up paint to the area of damage.	Six months
Floor vinyl	Ensure that any tears or damage to the floor vinyl and coved skirtings if specified are repaired, particularly in wet areas.	Six months
External Finishes	The external finish should be checked for scratches and marks and the appropriate touch up paint applied in accordance with manufacturer's instructions. The external finish can be cleaned using propriety cleaners such as domestic detergent diluted with clean water.	Six months
Electrical Installations	The electrical installation should be periodically inspected and tested in accordance with the IEE regulations.	As IEE requirements
Convactor Heaters	Convactor heaters should not be used for drying purposes, covered with garments, etc., due to the possible fire risk.	On going management
Floor loadings	The maximum floor loading capacity should not be exceeded.	
Door Hinges Roofs	Lightly oil to ensure trouble-free operation. Check roof joint seals	Annually
Sliding Shutters	Ensure shutter cord is not damaged and that the bearings run freely, if required replace cord and lubricate bearings	Annually

Electrical Specifics

Item	Details	Maximum Frequency
RCD (Main Switch)	Check the incoming R.C.D (MAIN SWICH) is working correctly and that it is checked regularly.	At each relocation or annually
Frost Protection	Ensure that insulation is in place and that it is not waterlogged. Check that any electrical heating installed for frost protection is in good working order, Especially before winter frost and cold weather. NOTE Frost stats are installed to turn heaters on when the temperature drops to near freezing and will not generally operate in the summer months. Frost protection heaters will only stop pipes from freezing, and are not for general space heating	Annually

Convactor heaters	The electrical installation should be periodically inspected and tested in accordance with the IEE regulations. Convactor heaters should not be used for drying purposes, covered with garments, etc., due to the possible fire risk. Desks should not be pushed over the tops of the convactor heaters.	As IEE Regulations
Drying Rooms	Tubular Heaters may be installed within Drying Rooms and are controlled via a room stat. These heaters are installed under benches and coat rails, providing a constant heat for keeping the temperature high for drying clothing. This heating will generally be supplemented by a larger high level fan heater. The fan heaters are used to boost the heating when clothing is wet. Once a high temperature is reached the tubular heaters will keep the room warm.	Annually
High level Fan Heaters	These heaters are either AC3 (3KW) OR 2 Dimplex FX 20 type heaters (2kw or 1 kw). Or equivalent. Under no circumstance should clothing be hung over these fan heaters. Besides being a major fire risk, this practise will void the warranty and cause the heaters to overload and burn out	Annually
Water Heating	Water heating is generally over sink or a under sink type. Each heater should have a 3 bar reducing valve fitted. See specification sheets. These water heaters have resettable thermal overloads, should an overload trip, the power can be turned off and back on. This will reset the overload. The overload will operate should the heaters be powered up with the water vessels empty. Heaters would not be starved of water. Should the water supply be disrupted, the power supply should be switched off. When the water is restored the water heaters need filling then the electric supply can be switched back on .	Annually
PIR, & cabin controls	Subject to specification, a cabin may have additional controls, typically for eco features. Check functionality, do not attempt to service or tamper.	Annually
All Electrical Appliances	Before faulty equipment is reported under warranty. Please check that the local Isolation to the equipment. This a switched fused spur and occasionally This fuses within the spur unit blow or are removed by people on site to fit into 13 amp plug tops.	Before reporting a problem

HEALTH & SAFETY

The responsibility for safe working with or on any Surefire unit or complex rests with the owner, or related contractor(s). Material safety data sheets relating to materials used within the building construction are available on request. In addition to advice given in the main text, your attention is drawn to the requirements of the Health & Safety at Work etc. Act, and in particular the following Regulations and Standards:

The Management of Health & Safety at Work Regulations (including the requirement of Risk Assessments for work or activities to be completed).

Lifting Operations and Lifting Equipment Regulations. BS7121 Mobile Cranes.

Electricity at Work Regulations (and IEE Requirements)

Control of Substances Hazardous to Health Regulations

Construction (Health, Safety and Welfare) Regulations

Construction (Design and Management) Regulations

BS6492: Part 2 Transportable Accommodation Units. (Transportation and Siting).

The list above is not intended as a definitive list, but a listing of the key features that may relate to users of Surefire buildings.

Further advice on these publications can be obtained from:

Health and Safety Executive and British Standards.

Every effort has been made to ensure the accuracy of the contents of this guide. It is however intended for guidance only and Thurston Building Systems can accept no responsibility whatsoever for any outcome of the use of advice herein. In accordance with Thurston Building Systems policy of continuous product development and improvement, we reserve the right to make design and specification changes without prior notice.